

## Udskiftning af pære

1. Always use Tops-lighting approved lamps type or professional Led light bulb suppliers.
2. Be careful not to bend the contact pin of the lamp during insertion into lamp holder.
3. Under cooled to change Led light bulb must be
4. Volatage of Led light bulb is DC12V G4 pin type.

